





PROPER HEIGHT

Ensure proper heights for guardrails:




TOE BOARDS

Toe boards must be installed to prevent materials and/or tools from falling to lower levels.



Screens or mesh must extend from the top rail to the walking/ working level and along the entire opening between rail supports.





PUTYOURGUARDUP.COM